



NOTES:

1. APPROVED REDUCED PRESSURE BACKFLOW ASSEMBLY (RPBA) TO LAY HORIZONTAL WITH GROUND. (VERTICAL ALLOWED IF APPROVED BY WA. DEPT. OF HEALTH)
2. DESIGN RPBA FOR BACK SIPHONAGE AND BACK PRESSURE.
3. THOROUGHLY FLUSH LINES PRIOR TO INSTALLATION OF BACKFLOW PREVENTER.
4. DO NOT INSTALL IN AN AREA SUBJECT TO FLOODING.
5. RPBA MUST BE ACCESSIBLE.
6. PROTECT RPBA FROM FREEZING.
7. A PLUMBING PERMIT IS REQUIRED-CONTACT THE APPROPRIATE JURISDICTION'S PERMITS COUNTER
8. RPBA MUST BE TESTED AFTER INSTALLATION, THEN ANNUALLY BY A WA. STATE CERTIFIED BACKFLOW TESTER. TEST RESULTS SHALL BE SENT TO THE CITY CROSS CONNECTION PROGRAM ADMINISTRATOR, (360) 835-2662 OR Backflowtestreports@cityofwashougal.us
9. RPBA SHALL BE APPROVED BY THE STATE OF WASHINGTON.
10. DRAIN SHALL BE SIZED PER THE AWWA CROSS CONNECTION CONTROL MANUAL
11. RPBA MUST BE RETESTED IF MOVED OR REPAIRED
12. AS OF JANUARY 4, 2014 ALL NEWLY INSTALLED FITTINGS IN CONTACT WITH WATER SHALL BE IN COMPLIANCE WITH THE REVISED SECTION 1417 OF THE EPA SAFE WATER DRINKING ACT AND CERTIFIED LEAD FREE USING NSF 372 STANDARDS.

(ABOVE GROUND INSTALLATION ONLY)



**2" & SMALLER REDUCED PRESSURE BACKFLOW
ASSEMBLY FOR DOMESTIC & IRRIGATION SERVICE
(OUTSIDE INSTALLATION)**

DATE: December 2016

DETAIL
NO.

W130